



AUF (UP) / AB (DOWN)
Set According to your
Screen's Connections

Relay Contact Connections
on the RP-6



Relay 1 Contact A: AUF (UP)
Relay 2 Contact A: AB (DOWN)

Relay 1 Contact B
and Relay 2 Contact B
(bridged): Ground